

WT 514 - MULTI-FUNCTION PROJECTION CLOCK

FEATURES:

Measuring temperature range: 0 ~ 50°C (32 ~ 122°F)

Measuring humidity range: 20 ~ 99%




Resolution: 1°C

Display: MIN/MAX temperature and humidity records

Calendar: 2001 -2099 year

Power: 4.5v adaptor (included) supplied and/or 2x UM-4/AAA (not included)


COMFORT LEVEL INDICATION:

	 DRY	 COMFORT	 WET	NO ICON shown
Temperature	at any degree	20 °C-25°C	At any degree	out of 20 °C-25°C
Humidity value	< 40% RH	40% RH-70% RH	>70% RH	40%RH-70%RH

WEATHER FORECAST:

The weather is based on the temperature and humidity chart to create the next 12-hour weather forecasts. This is meant as a fun addition to the clock as the reading is affected by indoor conditions such as air conditioning and central heating which will affect the accuracy.

They are 4 possible weather symbols shown below:



OPERATION:

Press MODE one time to view the alarm time.

Press MODE one more time to the view calendar.

SETTING THE TIME:

Press and hold MODE for 3 seconds to enter the time setting mode.

The hour digits are blinking and can be set by pressing UP or DOWN for setting hour.

Press MODE again:

The minute digits are blinking and can be set by pressing UP or DOWN for setting minute.

SETTING THE ALARM:

Press MODE for 2 times to view the alarm time.

Press MODE hold for 3 seconds to enter the alarm setting mode.

The hour digits are blinking and can be set by pressing UP or DOWN for setting hour.

Press MODE again:

The minute digits are blinking and can be set by pressing UP or DOWN for setting minute.

SETTING THE CALENDAR:

Press MODE to the view calendar.

Press MODE hold for 3 seconds to enter the calendar setting mode.

The year digits are blinking and can be set by pressing UP or DOWN for setting year.

Press MODE again:

The month digits are blinking and can be set by pressing UP or DOWN for setting month.

Press MODE again:

The day digits are blinking and can be set by pressing UP or DOWN for setting day.

ALARM ON/OFF:

Press UP to turn alarm on/off.

MAX / MIN:

Press MAX/MIN to view MAX temperature and humidity record.

Press MAX/MIN again to view MIN temperature and humidity record.

12/24 FORMAT HOUR:

At the time mode, Press UP for 3 seconds to switch 12 or 24 format hour time display.

TEMPERATURE DISPLAY FORMAT:

Press DOWN to switch °C/°F display.

SNOOZE/LIGHT/PROJECTOR:

During the alarm press SNZ for snooze mode.

Press LIGHT to turn on backlight for 5 seconds, and the projector will display the real time and weather icon on the opposite wall in dark room at the same time.

When clock is powered by 4.5v adaptor the projector is always working.

Use the adjustable projection arm to display onto appropriate wall or ceiling. Use the focus key to adjust the focus of the projected display.