



Example #1: Operations via start and end address under Address Mode.



DIRECT MODE

Example #2: Fixed Message Configuration Operations under Direct Mode.



DOCUMENTI E LINK UTILI

- [Schematic](#)
- [Eagle Files](#)
- [Datasheet \(ISD1932\)](#)
- [Sample Recording](#)